







# MASTER CONTROLLER SPARE COMPONENTS



## SPARES FOR MASTER CONTROLLER (IP-41)

			
<b>BOTTOM COVER</b>	<b>CAM SHAFTS BEARING END BUSHES</b>	<b>NOTCHING LEVER</b>	<b>NOTCHING SPRING ASSEMBLY</b>
			
<b>RACHET</b>	<b>RACHET</b>	<b>SPRING</b>	<b>TOP COVER</b>

## SPARES FOR MASTER CONTROLLER (IP-54)

				
<b>BOTTOM COVER</b>	<b>SPRING ARRANGEMENT</b>	<b>RACHET</b>	<b>SPRING</b>	<b>TOP COVER</b>

## SPARES FOR MASTER CONTROLLER (COMMON PARTS)

			
<b>CAM FULL PROFILE</b>	<b>DEAD MAN HANDLE/ BUTTON</b>	<b>END BUSH</b>	<b>FIXED AND MOVING CONTACTS</b>
			
<b>FIXED AND MOVING CONTACTS</b>	<b>HANDLE</b>	<b>START BUSH</b>	<b>SPRING RETURN ASSY</b>

H. O. Unit - I : C-15/16, Nand Jyot Industrial Estate, Andheri-Kurla Road, Mumbai - 400072 ,  
Tel : (022) 42469700/730  
E-mail : sales@socgroup.in

Unit - II: Plot No. 4912, G. I. D. C., Phase IV, Vatva, Ahmedabad - 382445  
Tel.: (079) 68169700/702/712  
E-mail : enquiry2@socgroup.in

Visit us at :  
www.speedocontrols.com  
www.socremote.com

**SPEED-O-CONTROLS PVT. LTD.**

**CRANE CONTROL GEAR V2**